

# REVISED INSTRUCTIONS For magic cutter (almost)

## HEIGHT GAUGE (straight tip)


Push tip lightly against plastic roller while turning wing nut.  
Adjustment is complete when tip moves to hit "O" ring.

## CUTTER (bent tip)

Start foiling at a corner, point or sharp outside curve.

End where roller is closest to the table.

Align foiled glass so its first foiled edge is close to square with angled edge of table, and still against the "O" ring, like drawing.



CAUTION: CUTTER END SHARP

Also see photo on package

1. IMPORTANT- With label facing straight up, align bent cutter tip flat against edge of foiled glass as shown.
2. Hold glass from turning and push cutter tip hard into roller. Hold this position for steps 3, 4 & 5\*.
3. Push glass to the right against cutter as shown by arrows\*\*.
4. Pull glass to your left away from roller.
5. Hold foil roll from turning and pull cutter to your left away from roller\*\*\*.

\* Sharp end cuts only center of foil

\*\* Leverage tears balance of foil for the "cut"

\*\*\* Leaves foil neatly in roller for the next piece of glass

## TESTIMONIAL:

"I knew it should work because you guys make good stuff but, I had a hard time using it." Dione Roberts of D & J's Glassworks, Billings, Montana.

We think its because the directions needed more clarity.

Perhaps these new instructions will hopefully make it "Almost Magic"

Please call us if it doesn't. 800-250-1790

With new instructions, Dione now says "I used it all last weekend and it works great!"